

DRAPE ARM 1.09/1.18 SCONCE - INSTALLATION INSTRUCTIONS



GLOVES (NITRILE) ARE PROVIDED AND **MUST BE WORN DURING INSTALLATION TO AVOID FINGERPRINTS ON THE FINISH OF THE EXPOSED METAL PARTS.**

Congratulations on your purchase of a SkLO Drape Arm 1.09/1.18 sconce. This product must be installed in accordance with the applicable codes by a person familiar with the construction and operation of the product and the hazards involved, preferably a licensed electrician. Use maximum 7W bulb.

- 1 The glass will be packed separately from the light fixture itself. Unpack the light fixture first and leave the glass packed until the light is installed. The threaded socket will have a protective packaging around them - leave this on until the light is fully installed and ready for the glass.
- 2 The canopy is meant to fit install directly to the wall surface around a recessed electrical box. Carefully supporting the fixture, center the canopy over the recessed electrical box, and mark the locations for the four fasteners through the four countersunk holes in the canopy.
- 3 Depending on your wall surface, determine if anchors are required for the installation, or if the supplied anchors are appropriate for your wall surface. Install an anchor (if using) into each of the four fastener locations.
- 4 Carefully feed the end of the cable through the tube at the end of the arm, and then through the hole in the canopy. Tighten the set screw at the side of the tube to set the length of the drop below the arm - do not overtighten or damage the electrical cord.
- 5 Leave some slack in the cord between the top of the arm and the canopy to allow the cord to drape gracefully. Then, trim any excess length of electrical cord - when trimming the fabric-wrapped electrical cords make sure to use electrical tape or other means to secure the fabric at the location of the cut, and then at the cut end to avoid splaying or fraying or slack in the fabric.
- 6 Supporting the fixture, connect the exposed leads on the fixture to the leads in the electrical box according to the wiring diagram (right).
- 7 Supporting the fixture, install by screwing the four provided screws through each of the four countersunk holes in the canopy and into the anchors (if using) on the wall surface, making sure that canopy sits flat and flush against finish surface.
- 8 Unwrap the protective packaging from the socket. Insert the supplied light bulb into socket. Unwrap glass shade, slip hole with threaded brass insert in shade over the light bulb and thread glass sphere onto socket. Thread the glass spheres on just until they are visually tight - do not overtighten.

