




DEW PENDANT

Installation Instructions

Congratulations on your purchase of a SkLO Dew Pendant. This product must be installed in accordance with the applicable codes by a person familiar with the construction and operation of the product and the hazards involved, preferably a licensed electrician. Use a maximum 7W bulb.

When unpacking individual items and parts of the light fixture, make sure to lay them out on a protective surface that will neither mar the delicate metal finishes nor scratch the glass. Gloves (nitrile) are provided and must be worn during installation to avoid fingerprints on the finish of the exposed metal parts.

Your SkLO fixture will arrive with the hand-blown glass elements packed separately from the light fixture itself.



CONTENTS:


Canopy + stem + light fixture assembly	Additional stem segment (longer OAD lengths only)	Metal sleeve	Glass element
1x	1x	1x	1x
Light bulb	quantity varies	Universal crossbar	Machine screw (1x) Wire connector (1x)
1x	1x	1x	2x 2x




1. Carefully remove the two set screws in the bottom part of the assembly and set them aside (Figure 1).
2. Install the supplied LED light bulb (7W Max) into the socket. This fixture uses G9 sockets and light bulbs. The G9 is a bi-pin socket. Light bulbs are to be inserted and removed by pushing the bulb straight into the socket, and by pulling it straight out. The bulb, when inserted, should have a tight fit. Do not force the bulb. If there is resistance, check to make sure nothing inside the socket is bent or obstructing the bulb. Always turn off the power to the fixture when changing the bulb(s) (Figure 2).
3. Slide the brass sleeve over the assembly. While holding it above the threaded holes, slide the glass diffuser into the bottom part of the assembly so that the holes in the glass align with the threaded holes in the brass and secure it in place with the two set screws. Thread the set screws just until they are aligned with the face of the assembly. Then carefully slide down the sleeve until it sits on the glass diffuser (Figure 3).
4. For lights with longer OAD lengths, the stem will be in multiple parts. Uncoil the electrical wiring at the top of the fixture and carefully pass the wires through each stem as you fasten them together and then the canopy at the end. To connect the stems, thread the open end of each stem onto the exposed nipple of the other (Figure 4).
5. Install the universal cross bar (provided) to the recessed electrical box with the provided 8/32 thread screws so that the 8/32 threaded holes spaced 2 3/4" on-center on the crossbar match the desired orientation of the fixture based on the countersunk holes in the canopy (Figure 5).
6. Connect the exposed leads of the fixture to the leads in the electrical box according to the wiring diagram using the wire and wire connectors provided. Attach the ground (TE) wire from light fixture to the dedicated place in the recessed electrical box, phase 1 (L1) + phase 1 (L1) from light fixture, neutral (N) + neutral (N) from light fixture (Figure 6).
7. Install light by fastening the two supplied 8/32 thread brass machine screws directly into the appropriate holes in the crossbar through the holes provided in the canopy, making sure that the canopy sits flat and flush against finish surface. Take great care when installing screws so that tools do not slip and scratch the canopy finish, nor damage the exposed screw head slots (Figure 7).






1.



2.




3.







4.



5.





6.





7.





SkLO

sklo.com

SkLO US 115 WEST NORTH STREET HEALDSBURG CALIFORNIA 95448 USA +1.707.385.2101 us@sklo.com
SkLO EU VÁŽNÍ 488 500 03 HRADEC KRÁLOVÉ CZECH REPUBLIC +420.495.542.071 eu@sklo.com